

Anlegevorgang des Dräger CPS 7900



In das linke Bein einsteigen und es wie eine Hose hochziehen.



Mit dem rechten Bein einsteigen und den Anzug bis zur Hüfte hochziehen.



Ist der Anzug mit Längen-
anpassung ausgestattet,...



...den Haken im Hüftgurt des
Pressluftatmers einhaken und
mit der Zuglasche auf die
eigene Körpergröße einstellen.



Ist der Anzug mit einem Regula-
tionsventil PT 120L oder einem
Air-Connect ausgestattet, den
internen Druckschlauch mit
dem Pressluftatmer verbinden.



Wenn vorhanden, den Hüftgurt
schließen und fest ziehen.



Den rechten Arm in den
rechten Ärmel stecken...



...und dabei den Kopf in die
Haube stecken.



Die Hand in den
Handschuh stecken.



Den Rucksack über den
Pressluftatmer führen.



Die linke Hand in Ärmel und
Handschuh stecken.



Den Lungenautomat
anschießen.



Mit den Händen die Haube
hoch halten und so den Ver-
schluss gerade ziehen. Den
Reißverschluss schließen.
Dabei nicht zu stark ziehen.



Sollte der Reißverschluss
stecken bleiben, leicht zurück-
ziehen und noch einmal pro-
bieren – sicherstellen, dass er
gut geschmiert ist. Abdeckung
schließen.



Ggf. die externe Luftquelle
anschießen.



Donning of Dräger CPS 7900



Put your foot through the left leg and pull it up like a pant leg.



Put your right foot through the other leg and pull the suit up to your hips.



If the suit is equipped with height adjustment, attach the hook of the SCBA hip strap...



...and use the pull tab to adjust the suit to your own height.



If the suit is equipped with a PT 120L regulation valve or an Air Connect, connect the internal pressure hose to the SCBA.



If fitted, close and tighten the hip strap.



Put your right arm through the right sleeve...



...while placing your head in the hood.



Put your hand into the glove.



Pull the backpack over the SCBA.



Put your left hand through the sleeve and then in the glove.



Connect the LDV.



Hold the hood up with your hands and straighten the zipper. Close the zipper. Do not apply too much force.



If the closing system gets stuck, pull it backwards a little and try again – ensure good lubrication. Close the cover flap.



As applicable, connect the external air supply.

